




Thank you for choosing the Swiitech T ONE Wireless 2 in 1 Adapter Please read this guide carefully and keep it in a safe place for future reference If you need any further assistance, please contact our customer support team at service@iswlitech com

What's in the box?



Package Contents

(A) Wireless 2 in 1 Adapter x 1 B Type C Charging Cable x 1

(C) 3.5mm Audio Cab e x 1 D 3 5mm Female to 2 RCA Male Cable x 1

© User Guide x 1


© 3.5mm Audio Plug x 1

Product Materalu

① MFB(Multi functional Button) 3 Volume -/Previous Track (5) Mode Switch Button 7 LED Indicator A

(9) Power LED Indicato

2 Charging Port 4 Volume +/Next Track (6) 3.5mm Audio Port 8 LED Indicator B




Specifications

etooth Profile	A2DP/AVRCP
dio Codec	SBC/aptX
nge	33ft/10m
arging Power	DC5V
ttery Capacity	300mAh
orking Time	Approx. 26hours
arging Time	2 hours
mensions(LxWxH)	56.5mm x 35mm x 14mm
eight	20g

ខេត្តថ្ងៃ 🕶 🕶 💮

MFB

In RX/TX mode, press and hold "MFE Single click "MFB" in RX mode(When paying music) Play/Pause



NOTE • Press and ho d the power button for 1 seconds The adapter will automatically enter its pairing state. During this time, the LED Indicator A&B will alternately f ash blue. If the adapter discovers a previously connected de ce, it will connect If not, it will wait for a new de ce to try to connect to Within 3 minutes, If no connection is made after 3 minutes, the adapter will automatically

Power off

• Press and ho d the power button for 5 seconds. The red power LED indicator will light for 1 second and then the adapter will shut off.

1.881

Volume /Previous Track

wiste sontole her beving music

Types 1 3.5mm Audio cable

In RX mode, singe c ck Volume+ o ume-Next/Previous Track In RX mode press and hold Volume+ olume

•In TX mode, there are no Play/Pause, Volume +/-, Next/Pre ous Track functions available

Turn the mode switch button to RX Turn the mode switch button to TX

• In standby or connection mode, you can freely switch between TX and RX modes. After switching modes the connected devices from the last mode will be disconnected, and the adapter will enter its pairing state


LED Indicators

So id blue

So id red

So id blue

LED off



No Bluetooth de ice paired in TX, RX mode

2 The LED indicator will turn red when adapter is charging. It will turn blue when the device is charged and charging will stop automatically

Charging

•We recommend charging the unit for at least 2 hours before using it for the first time •When the adapter needs to be used continuously for longer than the battery lasts, it can be connected to a charging power supply while you are using it •It is not re ommended that you use this function frequently because it may affect the service

n the cha ging state, press and hold volume + & volume for several seconds (in TX/RX mode),

How to enter remains more metrosity?

MFB S

2 The LED indicators A and B will flash blue alternatively.

all B uetooth de ices connected to the adapter will be cleared

1 Use a USB Type C cable and connect the adapter to any active Type C port

restore នាចាប់ក្នុងទៅប្រទ

For when the adapter is already connected to a Bluetooth device in TX/RX mode

1 Double-c ick the "MFB" button of the adapter to enter pairing mode

Apple (magains - earn) Wol



1 Set the adapter to TX mode connect it to your Non Bluetooth device player, etc.) Connect one end of a 3 5mm audio cable/plug into the audio port of the adapter, and the other end into the audio out jack of the Non Bluetooth device

2 Bring your Bluetooth audio receiving device(earphones, speakers etc. .) within a 3 feet/ 1 meter range and power it on Set it to pairing mode

3 Press and hold the power button of the adapter for 3 seconds to turn it on and enter pairing mode The LED indicator A and B of the adapter will alternate y f ash blue At this point, the nearby Bluetooth receiving device will automatically connect to the adapter, then the led indicator A on the adapter will become solid blue, the led indicator B will be off.

NOTES(In TX mode)

• A 3.5mm female to 2 RCA male cable is suitable for connecting the adapter to a TV without a 3.5mm audio output jack. This cable is included in the package

•In pairing mode, if there is no Bluetooth device connected to the adapter, the Bluetooth indicator light will f ash for 3 minutes and the adapter will automatically shut down

•After the first successful connection, if the adapter and Bluetooth device are turned on again the adapter and Bluetooth device will automatically connect

In TX mode, the adapter is able to pair with two Bluetooth stereo earphones speakers at the same time

1 Follow the pre ious instructions in the "How to use Pairing in TX mode" section to pair the adapter with your first device

2 Double click the adapter "MFB" button to enter pairing mode(The LED indicator A and B of the adapter will alternately flash blue)

3 Turn on the second Bluetooth device Make sure this device is also in pairing mode

4 Move the adapter and the second device close together and the pairing will be completed

5 After pairing is comp eted, the LED indicators A and B of the adapter will turn blue and

•To ensure that the adapter will successfully pair with the two Bluetooth devices you want to connect to, make sure there are no other Bluetooth devices within 10 meters of the adapter, especially those that have previously paired with your Bluetooth

 $\bullet \mbox{When the adapter}$ is paired with the second Bluetooth device, the first Bluetooth

•When you pair with two devices, both can play music at the same time



1 1 Set the adapter to RX mode and insert one end of a 3 5mm audio cable/plug into the audio port of the adapter Insert the other end into your Non Bluetooth audio receiving

2 Press and hold the power button of the adapter for 3 seconds to turn it on and enter pairing mode. The LED indicator A and B of the adapter will alternately f ash blue

3 Activate the Bluetooth function on your transmitting device(phone, tablet, etc) and search for nearby Bluetooth devices

4 Find "T-ONE" in the search results and tap on it to connect. Once connected, the LED indicator A on the adapter will be solid blue the LED indicator B will be off

NOTES(In RX mode)

•In pairing mode if there is no Bluetooth device connected to the adapter the Bluetooth indicator light will flash for 3 minutes and the adapter will shut down

• After the first successful connection, if the adapter and Bluetooth device are turned on again, the adapter and Bluetooth device will connect automatically

In RX mode, the adapter is able to pair with two Bluetooth devices at the same

1 Follow the previous instructions in the "How to use" Pairing in RX mode" section to pair he adapter with your first device

2 Double click the adapter "MFB" button to enter pairing mode(The LED indicator A and B of the adapter will alternately flash blue 3 Turn on the second Bluetooth device. Find "T ONE" in the search results and tap on it to

4 After pairing is completed, the LED indicators A and B of the adapter will turn blue and remain on. At this time the adapter has already connected to two Bluetooth devices

•Only one device can play music through the adapter at any time. You have to stop the music one the one dev ce to play on the other

•When the adapter is paired with the second Bluetooth device, the first Bluetooth device will not disconnect from the adapter

• If the adapter is already connected to two Bluetooth devices simultaneously, double click the "MFB" button and the adapter will enter pairing mode and c ear the two connected Bluetooth devices

•In RX mode, you can operate the volume bittons on the adapter to control the volume

Step 1 Using the 3.5mm audio cable we provided to connect your TV to the adapter (In mode) Long press the power button of the adapter (In TX mode), then turn on your Bluetooth headset or other device and bring it close to the adapter. After the pairing is ccessful, you should be able to hear your TV through the headset.


Step 2 If not, check your TV settings to make sure that the TV speaker has been set to



Types 2 RCA cable

10

Step 1 For RCA this option Please Only Use the port labeled "audio out" Any other port will



be able to hear your TV through the headset Step 3: If not, check your TV settings to make sure your TV speaker is set to external speaker



Step 2: Connect the 3.5 mm audio cable to the RCA aux converter cable that we provided

then use this to connect your TV to the adapter (in TX mode). Turn on your Bluetooth headse

or other device and and move it near the adapter. After the pairing is successful, you should

PRECAUTIONS

1. When power is low or the adapter is not used for a long time, it should be charged before use to prevent the product from working abnormally or receiving battery damage

2. Bluetooth signals will be blocked and absorbed by surrounding objects. For the best sound quality, try to use the adapter in a direct line-of sight with your connected device

3. The adapter has a built in lithium battery, please charge frequently when using it

4 Please keep the adapter away from water or other liquids to avoid damage

5 If you have any problems, please feel free to contact us at service@iswitech com and we

@Bluetooth®

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc And any use of such marks by sunvalleytek international inc is under license. Other trademarks and tra de names are those of their respective owners

Note This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

If not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no quarantee that interference will not oc ur in a particular installation. If this equipment does cause

equipment generates, uses and can radiate radio frequency energy and,

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

the following measures

Regrient or relocate the receiving antenna

-Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

—Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference and

(2) this device must accept any interference received, including interference that may cause undesired

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

he device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction

Swiitech

尺寸:92*110mm 材质:105g铜版纸 折叠方式:风琴折页

service@iswitech.com CES A MADE I