

BTBIKE QUICK GUIDE (DRAFT)

POWER ON/OFF:

- ON: Long press **MFB** until led turn blinking **blue** and ascending tone can be heard.
- OFF: Very long press **MFB** until led turn **red** and descending tone can be heard.

INTERCOM PAIRING:

1. From off, press and hold **MFB** on each unit until the LED flashes **red/blue**.
2. Then short press **MFB** on one of the two units.
3. If 2 BTBIKE are successfully paired, both LED flashing steady **blue** and intercom communication heard on both HS.

INTERCOM CONNECT:

- Long press-Release **MFB** until the beep to connect to intercom.

INTERCOM DISCONNECT:

- Long press-Release **MFB** until the beep to disconnect intercom.

PAIRING BTBIKE TO A BLUETOOTH MOBILE PHONE:

* Pairing from OFF :

1. From off, press and hold **MFB** until the LED flashes **red/blue**.
 2. On your phone, turn on the Bluetooth function then search for devices
 3. Select **BTBIKE R21** on the list of devices to have the phone connected.
- When **BTBIKE** is successfully paired to phone, LED blinks **blue** twice every 2 sec.

USING BTBIKE WITH A BLUETOOTH MOBILE PHONE :

A2DP MUSIC STREAMING

Play/Pause A2DP :

- Long press **MFB** until the 2nd beep to Play/Pause music.

Go to Next/Previous song :

- Next song : Long press-Release **VOL+** until the beep to go to next music.
- Previous song : Long press-Release **VOL-** until the beep to go to previous music.

PHONE CALL :

Answer call :

- Short press **MFB** to accept the call.

End call :

- Short press **MFB** to end ongoing phone call.

Reject incoming call :

- Long press-Release **MFB** until the beep to reject incoming call.

Redial :

- Double press **MFB** to redial last used.

Voice Dial :

- Short press **MFB** to activate Voice Dial.

3-WAY CALLING :

Ongoing Call + Incoming ring

Accept 2nd call and end current call :

- Short press **MFB** to accept incoming call and end current call

Accept 2nd call and current call on hold :

- Long press-Release **MFB** until the beep to accept incoming call and current call on hold

Reject 2nd call and current call continue :

- Long press **MFB** until the 2nd beep to reject incoming call

Ongoing Call + On hold call

End current call and retrieved on hold call :

- Short press **MFB** to end current call and retrieved on hold call

Put current call on hold and retrieved the on hold call :

- Long press-Release **MFB** until the beep to put current call on hold and retrieved the on hold call

End on hold call and current call continue :

- Long press **MFB** until the 2nd beep to end on hold call and current call continue

ADJUST VOLUME :

- Short press **VOL+ / VOL-** to increase or decrease the audio volume. A high or low beep will be heard upon reaching maximum or minimum level.

Charging BTBIKE unit:

Connect a USB type-C cable into the device socket.

The LED will turn **red** while charging.

The LED will turn **green** once the battery is fully charged.

Reset and erase pairings :

- From OFF, long press **MFB, VOL- & VOL+** at the same time until it turn on then double beep heard and LED blinks **purple** twice then turn OFF. *(Note : All paired devices will be deleted)*

SPECIFICATIONS:

Bluetooth compliance:	Bluetooth® version 5.1
Multipairing:	Maximum 8 phones paired / 1 phone connected at a time
Operating range:	upto 10 meters (Bluetooth standard)
Frequency range:	2.402 - 2.480 GHz
Battery type:	200 mAh Li-Po
Charging time:	3 hours (depending on charger)
Operating temperature:	0 to 45°C
Charging temperature:	10 to 40°C
DC input:	5VDC 0.1A
Storage temperature:	-10 to 60°C
Accessories:	1 USB cable

WARNING:

To prevent possible hearing damage, do not listen at high volume levels for long periods.

CAUTION:

- The disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems).



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

This product has an embedded, non-replaceable battery, do not attempt to open the product or remove the battery as this may cause injury and damage the product. Please contact the local recycling facility for removal of the battery. The embedded, non-replaceable battery is designed to last the life time of the product.



Hereby, EURO COMMUNICATION EQUIPEMENTS declares that the radio equipment type BTBIKE is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

<http://www.SuperTooth.net/download>
Euro Communication Equipements sas
Route de Foix D117
11 500 NEBIAS
FRANCE

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Euro-CB is under license. Other trademarks and trade names are those of their respective owners.